

Cross Point Switch using MAQ20-DORLY20 Module

The MAQ20 relay module, MAQ20-DORLY20, contains 20 relays that may be wired as a 4x5 cross point switch as shown in the figure 1 below. The numbers 1-40 represent the 40 spring terminals of the module. The labeled connections C0-C4 and R0-R4 are system connections.




Figure 1: Wire diagram of MAQ20-DORLY20 used as 4x5 cross point switch.

The MAQ20-DORLY20 in such configuration as cross point switch can find valuable use in many applications. One example is the use in a manufacturing or distribution center conveyor.



Let's imagine that up to 5 machines or operators produce outputs, C0-C4, for the next operation, R0-R4. Up to four machines or operators are to receive the Cx outputs. When a C station signals completion to the conveyor controller, the controller picks the C output, but takes no further action unless, or until, an R station is ready, or becomes ready, for input.

If C2 station has been picked and R1 becomes available for input the controller closes relay C2-R1. This in turn causes the conveyor to move to and place its container at the R1 station.


For Application and Technical Support call +1-800-444-7644

The following table lists the relay cross reference:

System Connection	Relay Number
C0-R0	1
C0-R1	6
C0-R2	11
C0-R3	16
C1-R0	2
C1-R1	7
C1-R2	12
C1-R3	17
C2-R0	3
C2-R1	8
C2-R2	13
C2-R3	18
C3-R0	4
C3-R1	9
C3-R2	14
C3-R3	19
C4-R0	5
C4-R1	10
C4-R2	15
C4-R3	20

The relay module, MAQ20-DORLY20 in combination with the MAQ20-COMx module, may also be used for other applications by wiring it as one of several multiplexer purposes, or just driving 1 to 1 to machine contactors.

The MAQ20 discrete input module, MAQ20-DIVC20, may be used to detect signals from C and R functions. A simple MAQ20 system built with just two modules, the MAQ20-COM and MAQ20-DORLY20 can control a multi-input, output conveyer.



For Application and Technical Support call +1-800-444-7644